

MR2 Turbo No Spark or Fuel

Posted by finnegan777 - 2016/05/14 13:19

well hello folks, its been quite awhile :lol:i know this is a well covered topic but none of the threads have any answers for me..... anyway i recently acquired a rev 1 and rev2 mr2 turbo. i have one of them running perfect however the second one refuses to run. its not getting spark or fuel. i changed the distributor and ecu but still not a thing.. it did try to fire up once but that was it, fuel and spark stopped... all fuses and relays seem fine and all have power at them. The lambda sensor has been cut and joined in a few places but thats all i can see... would a wire be broke going from the ecu till the distributor as i believe thats the crank sensor.. ??

=====

Re: MR2 Turbo No Spark or Fuel

Posted by Quandry - 2016/05/16 14:35

Could be a lot of things I guess :/

I would recommend start at this page: http://mr2.ie/mr2/bgb/mk2/mechanical/index_mechanical.html

Go to the EFI chapter and look at troubleshooting. Hopefully running through that should give you some clues to where the issue is.

=====